

Diesel Fuel

Order No. 81 03 475

C

Application Range

Standard Measuring Range:	25 to 200 mg/m ³
Number of Strokes n:	5
Time for Measurement:	approx. 2.5 min.
Standard Deviation:	–
Color Change:	white → brown

Ambient Operating Conditions

Temperature:	0 to 40 °C
Absolute Humidity:	≤ 40 mg H ₂ O / L

Reaction Principle

Undecane + I₂O₅ = I₂

Cross Sensitivity

Various organic compounds with changing sensitivity are displayed.



ST 364-2008