

# Dräger HPS® 7000 Head Protection

The Dräger HPS® 7000 firefighter's helmet is in a class of its own, thanks to its innovative, sporty and dynamic design, ergonomic fit and components which make it a multifunctional system solution. It provides optimum protection during every operation.



# Dräger HPS® 7000



#### Mask-helmet connection

Adjustable, universal mask receptacle (only for Standard and PRO versions)

#### **Benefits**

#### Firefighting helmet with tailor-made fit for every head

To meet this requirement, Dräger developed the HPS® 7000 firefighting helmet in close cooperation with customers worldwide. Two helmet shells for head sizes from 50 to 66 cm cover a wide range of individual head and face shapes. With a weight of approx. 1,380 g in the basic version, it is one of the lightest helmets in its class. In addition to its comfortable interior fitting made of skin-friendly, anti-allergic and flexible materials, the Dräger HPS 7000 stands out with its high level of operating and wearing comfort.

#### Comfort is a matter of position

The padded 4-point harness allows for safe and easy adjustment to any head shape. The optimum balance of the firefighting helmet can be adjusted individually in the neck and chin area. The padding made of Nomex® also ensures a comfortable fit. The integrated comfort hairnet enables the height to be adjusted and assures a good climate inside the helmet. During operation, the head size can be adjusted quickly via an easy-to-operate size-adjustment wheel with a safety mechanism on the outer shell, even with wet and thick gloves.

Nomex® is a registered trademark of the company DuPont.

#### Design at its strongest

The ergonomic firefighting helmet design evenly distributes the weight to the head and relieves the neck muscles. The large and modern facial protection visor offers unrestricted protection with best visibility. For operations under chemical protective suits, the visor can be fixed permanently. A safe alternative is provided by the integrated and individually adjustable protective goggles with an integrated soft-pad edge protection. Both visors leave enough space for the simultaneous use of corrective glasses or respiratory masks. A firefighter's helmet is more than a mere piece of equipment – it serves as a personal distinguishing feature. Therefore, you can configure the helmet according to your wishes: select from a variety of colours and also pick an individual emblem for your front plate.

#### Innovative system design

As a provider of integrated system solutions, Dräger sets new standards for the interaction of its products. The universally and individually adjustable mask connection system of the Dräger HPS 7000 creates a strong and safe helmet-mask combination. The full-face mask FPS 7000, the integrated mask communication units Dräger FPS-COM 5000 or FPS-COM 7000 and the SCBA of the PSS series allow you to optimally configure the overall system. The lightweight LED helmet lamp is integrated into the helmet shell and illuminates the whole working area. It is located in the centre of the front plate and has an effective glare shield as well as an intelligent battery management system. The interior fitting can be equipped with various audio/speech headsets for different radios. This ensures reliable communication even in loud environments.

#### **Benefits**

#### Highest safety - the material mix makes the difference

Despite its low weight, the Dräger HPS 7000 firefighting helmet is one of the safest full-shell helmets in its class. Its outer shell of composite material in combination with the PUR inner shell provides reliable protection against thermal and mechanical influences. The plastic reinforced with fibreglass and aramid webbing resists extreme temperatures. It is even able to withstand the enormous radiation caused by the heat and flame engulfment of a flash over. The visors, made of high-temperature-resistant polyether sulphone, reliably protect your eyes and face against high heat, particles and liquid chemicals.

#### Nothing left to be desired

A comprehensive accessory programme completes the Dräger package. Reflective stripes improve your visibility under unfavourable conditions and allow for individual marking. Matched to your clothing, the various neck-protection versions reliably keep your back free. Separate helmet lamps are attached with a lamp adapter on the right or left helmet side. A Nomex® fabric protects your firefighting helmet in any training situation and extends its service life. Helmet bags and cases provide safe storage and transport.

#### Ready again in no time at all

The Dräger HPS 7000 firefighting helmet is easy and efficient to service, thanks to the minimum number of components. The entire interior fitting can be removed and reinstalled in just a few steps. You can replace individual components easily and quickly using standard tools. All helmet components are cleaned and disinfected manually or in an industrial washing machine.

#### **Outstanding design**

The firefighter's helmet Dräger HPS 7000 has been awarded three major design awards:

- Red dot design award 2013
- IF product design award 2014
- German Design Award Special Mention 2015

The awards count among the most important national and international design competitions and not only rate design quality, but also aspects such as safety, ergonomics, functionality, degree of innovation and environmental compatibility.

The red dot jury based its decision on: "The notably light Dräger HPS 7000 firefighter helmet can be customised to comfortably fit any head size and guarantees enhanced safety."

#### Awards







#### System Components



#### Dräger FPS® 7000

The Dräger FPS® 7000 full face mask series sets new standards in terms of safety and wearing comfort. Thanks to its enhanced ergonomics and the availability of multiple sizes, it offers a large, optimised field of vision and a very comfortable, secure fit.



#### Dräger FPS®-COM 5000

Because there is no time for misunderstandings in an emergency: The Dräger FPS®-COM 5000 communication unit has been specifically developed for the full-face mask Dräger FPS® 7000 and ensures clear communication through a voice amplifier unit or radio device – even under extreme conditions.

#### Accessories



#### Facial Protection Visor PESU for Dräger HPS® 7000

The integrated, large and ergonomic facial protection visor made of polyethersulfone protects you safely from extreme heat, particles and liquid chemicals. It also offers the best visibility. It is made to fit a wide range of individual face sizes and shapes, including the wearing of corrective spectacles. The visor is available in different versions: clear, clear/anti-scratch coating, gold-plated (protection against heat radiation) or anti-fog coating.



#### Protective goggles for Dräger HPS® 7000

The protective goggles are operated from the outside by two levers (suitable for both left- and right-handed use) and have a 2-position setting for adjustment to individual face sizes and shapes including the use of corrective spectacles. The integrated soft-pad edge protection ensures a comfortable fit. The protective goggles are available in different versions: clear, clear/anti-scratch coating and tinted exclusively for the Dräger HPS® 7000 PRO.



#### Neck protection for Dräger HPS® 7000

The neck protection can be quickly and securely attached via a plug-in system with four snap fasteners. Several designs are available:

- Short, close-fitting aramid version with integrated fold
- Alu-aramid version in different lengths
- Dutch version made of a 3-layer, high-quality aramid fabric, resistant to many acids and alkalis



#### Helmet lamp LED for Dräger HPS® 7000

The light-weight LED helmet lamp is integrated into the helmet shell and illuminates the whole working area. It is located in the centre of the front plate and has an effective glare shield. The 3W high-performance LED has three modes and two lighting levels (bright, dimmed, off). A function and battery test is integrated and the battery status is displayed during use.

#### Accessories



#### Lamp Dräger PX1 LED

High-performance lamp with new LED technology. The lamp can be attached on the left and/or the right side of the helmet.

#### Related Products



#### Dräger HPS® 3500

The Dräger HPS® 3500 – a multifunctional and universal helmet for the diverse requirements of rescue teams during search and rescue, forest and bush fire fighting, traffic accidents, rescue from heights, water rescue and any kind of technical assistance.



#### Dräger HPS® 4500

The Dräger HPS® 4500 is a traditional half-shell helmet with a modern design. Its robust outer shell provides you with excellent protection against impact and extreme heat. With a modern visor design, the helmet has superior wearer comfort due to ergonomic and lightweight internal components. A comprehensive range of accessories make our solution a truly versatile helmet across a variety of applications.

## Technical Data

Dräger I	HPS®	7000
----------	------	------

Size	Two helmet shell sizes, H1: for head size 52 to 60 and optional for		
	50/51 (when using a separate padding strip),		
	H2: for head size 56 to 64/66, continuously adjustable via		
	adjustment wheel		
Weight	HPS® 7000 Basic-H1: ca. 1,380 g (±5 %)		
	HPS® 7000 Basic-H2: 1,680 g (±5 %)		
	HPS® 7000 Standard-H1: ca. 1,480 g (±5 %)		
	HPS® 7000 Standard-H2: 1,780 g (±5 %)		
	HPS® 7000 PRO-H1: ca. 1,580 g (±5 %)		
	HPS <sup>®</sup> 7000 PRO-H2: 1,880 g (±5 %)		
Material, outer shell	Composite consisting of fibreglass-reinforced plastic (PA-GF) and		
	additionally reinforced with aramid webbing, high-temperature- resistant		
Colours	luminescent yellow		
	luminescent		
	RAL 9010 – white		
	RAL 3000 – red		
	RAL 1026 – bright yellow		
	RAL 1018 – zinc yellow		
	RAL 2005 – bright orange		
	RAL 5005 – signal blue		
	RAL 9005 – black		
	RAL 9006 – white aluminium		
	RAL 6018 – yellow green		
	chrom		
Mask connection (only for PRO version)	Option to attach any adapter mask, e.g. Dräger FPS® 7000, adjustable to four positions		
Interior fitting	Flame-resistant and washable 4-point harness made of Nomex®,		
	sweat band of eco-leather, head support ring with wheel-		
	adjustment system (patent pending), integrated comfort		
	hairnet, fixing lever for facial protection visor and communication adapter		
Facial protection visor	2.5 mm polyether sulphone, approved acc. to EN 14458:2004 with the options -40 °C, T, K, N, Ω, UV 2–4,		
	IR 4–4 depending on versions: clear, clear with anti-scratch		
	coating, clear with anti-fog coating or gold-coated		
Protective goggles (only for PRO version)	Variant clear or clear with anti-scratch coating:		
, , , , , , , , , , , , , , , , , , , ,	2.5 mm polyether sulphone with softpad edge protection,		
	approved acc. to EN 14458:2004		
	with the options -40 °C, T, K, $\Omega$ depending on version, adjustable		
	to two positions		
	Variant tinted:		
	2,5 polycarbonate with softpad edge protection, grey tinted with		
	60 % absorption, approved acc. to EN 166:2001, ultraviolet filter		
	2C-2, sun glare filter 5.2, optical class 1, strength class BT		
	(120 m/s), adjustable to two positions		
Approvals, helmet	EN 443:2008 (type B 3b, C, E2, E3, -40 °C), mask-helmet combination acc. to DIN 58610		
Helmet lamp HPS® 7000			

## Technical Data

Total dimension	Approx. 55 mm wide x 43 mm high x 105 mm long	
Weight	With batteries: approx. 125 g, without batteries: approx. 80	
Light technology	Power LED, lighting level 1: approx. 43 lm, lighting level 2:	
	approx. 25 lm	
Power supply	2 AA/LR6/MN1500 alkaline batteries, intelligent battery-	
	management system	
Usage time	Lighting level 1: approx. 5 hours	
	Lighting level 2: approx. 11 hours	
Protection class	IP67	
Approval HPS® 7000 helmet lamp	IECEx: Ex ib IIC T4/T3 Gb	
•	ATEX: II 2G Ex ib IIC T4/T3 Gb	

Variants	Dräger HPS® 7000	Dräger HPS® 7000	Dräger HPS® 7000
	Basic	Standard	PRO
Helmet shell in different colours	yes	yes	yes
Front plate	yes	yes	yes
Reflective stripes	optional	optional	optional
Integrated facial protection visor	yes	yes	yes
Integrated protective goggles	no	no	yes
Possibility of using Helmet- mask combination	no	yes	yes
Connection of integrated HPS® 7000 helmet lamp optional upgradable	optional	optional	optional
Optional connection of external helmet lamp	no	optional	optional

# Ordering Information

Dräger HPS® 7000 Basic, with matt-black front plate, without reflective stripes	Order No. H1	Order No. H2
Dräger HPS® 7000 Basic luminescent	R 79 170	-
Dräger HPS® 7000 Basic red	R 79 172	-
Dräger HPS® 7000 Basic bright yellow	R 79 173	
Dräger HPS® 7000 Basic black	R 79 177	-
Dräger HPS® 7000 Standard, with matt-black front plate, without reflective stripes	Order No. H1	Order No. H2
Dräger HPS® 7000 Standard luminescent	R 79 364	-
Dräger HPS® 7000 Standard white	R 79 366	-
Dräger HPS® 7000 Standard red	R 79 368	-
Dräger HPS® 7000 Standard bright yellow	R 79 353	-
Dräger HPS® 7000 PRO, with helmet shell and front plate in	Order No. H1	Order No. H2
same colour, silver reflective stripes and Dräger Logo		
Dräger HPS® 7000 PRO red	R 79 182	-
Dräger HPS® 7000 PRO bright yellow	R 79 183	-
Dräger HPS® 7000 PRO, with matt-black front plate, silver reflective stripes and Dräger Logo	Order No. H1	Order No. H2
Dräger HPS® 7000 PRO luminescent	R 79 250	R 79 420

# Ordering Information

Dräger HPS° 7000 PRO red         R 79 252         -           Dräger HPS° 7000 PRO bright yellow         R 79 253         R 79 423           Dräger HPS° 7000 PRO black         R 79 257         -           Dräger HPS° 7000 PRO chrome         R 79 259         -           Further versions of the Dräger HPS° 7000 are available on request, via configurator system number         R 79 571         R 79 572           Accessories / Spare parts           Neck protection aramid, aluminium short         37 00 329         37 00 329           Neck protection aramid, aluminium XXL         R 79 480         R 79 145           Neck protection aramid, short         R 79 480         R 79 480           Neck protection aramid, Dutch version, three-layer         R 79 146         R 79 146           Neck protection aramid, Dutch version, three-layer         R 79 147         R 79 147           HPS° 7000 helmet lamp LED, integrated         R 79 013         R 79 147           HPS° 7000 helmet lamp LED, integrated lengh, order separately: kit         R 79 226         R 79 226           front plate for HPS° 7000 helmet lamp         R 79 226         R 79 226           front plate for Adaro helmet lamp         R 79 493         R 79 493           Com plug protection for HPS° 7000         R 80 042         R 80 042           Helmet lamp Dr
Dräger HPS® 7000 PRO black         R 79 257         -           Dräger HPS® 7000 PRO chrome         R 79 259         -           Further versions of the Dräger HPS® 7000 are available on request, via configurator system number         R 79 571         R 79 572           Accessories / Spare parts           Neck protection aramid, aluminium short         37 00 329         37 00 329           Neck protection aramid, aluminium XXL         R 79 145         R 79 145           Neck protection aramid, short         R 79 480         R 79 480           Neck protection aramid, Dutch version, three-layer         R 79 146         R 79 146           Neck protection aramid, Dutch version, three-layer         R 79 147         R 79 147           HPS® 7000 helmet lamp LED, integrated         R 79 013         R 79 013           To attach the integrated LED helmet lamp, order separately: kit         R 79 226         R 79 226           front plate for HPS® 7000 helmet lamp         R 79 129         R 79 129           Lamp holder HPS® 7000 (for helmet lamp         R 79 493         R 79 493           Com plug protection for HPS® 7000         R 80 042         R 80 042           Helmet lamp Dräger PX 1 LED         R 62 350         R 62 350           HPS® 7000 facial protection PESU, clear         R 79 239         R 79 463           <
Dräger HPS® 7000 PRO black         R 79 257         -           Dräger HPS® 7000 PRO chrome         R 79 259         -           Further versions of the Dräger HPS® 7000 are available on request, via configurator system number         R 79 571         R 79 572           Accessories / Spare parts           Neck protection aramid, aluminium short         37 00 329         37 00 329           Neck protection aramid, aluminium         R 79 145         R 79 145           Neck protection aramid, short         R 79 480         R 79 480           Neck protection aramid, butch version, three-layer         R 79 146         R 79 147           Neck protection aramid, Dutch version, three-layer         R 79 147         R 79 147           HPS® 7000 helmet lamp LED, integrated         R 79 013         R 79 013           To attach the integrated LED helmet lamp, order separately: kit         R 79 226         R 79 226           front plate for HPS® 7000 helmet lamp         R 79 129         R 79 129           Lamp holder HPS® 7000 (for helmet lamps Dräger PX 1)         R 79 129         R 79 493           Com plug protection for HPS® 7000         R 80 042         R 80 042           Helmet lamp Dräger PX 1 LED         R 62 350         R 62 350           HPS® 7000 facial protection PESU, clear         R 79 260         R 79 463
Dräger HPS® 7000 PRO chrome         R 79 259         -           Further versions of the Dräger HPS® 7000 are available on request, via configurator system number         R 79 571         R 79 572           Accessories / Spare parts           Neck protection aramid, aluminium short         37 00 329         37 00 329           Neck protection aramid, aluminium XXL         R 79 145         R 79 145           Neck protection aramid, aluminium XXL         R 79 480         R 79 480           Neck protection aramid, short         R 79 146         R 79 146           Neck protection aramid, Dutch version, three-layer         R 79 147         R 79 147           HPS® 7000 helmet lamp LED, integrated         R 79 013         R 79 013           To attach the integrated LED helmet lamp, order separately: kit         R 79 226         R 79 226           front plate for HPS® 7000 helmet lamp         R 79 129         R 79 129           Lamp holder HPS® 7000 (for helmet lamps Dräger PX 1)         R 79 129         R 79 493           Com plug protection for HPS® 7000         R 80 042         R 80 042           Helmet lamp Dräger PX 1 LED         R 62 350         R 62 350           HPS® 7000 facial protection PESU, clear         R 79 239         R 79 463           HPS® 7000 facial protection PESU, AS (anti-scratch coated), clear         R 79 260
Accessories / Spare parts  Neck protection aramid, aluminium short  Neck protection aramid, aluminium  R 79 145  R 79 145  Neck protection aramid, aluminium  R 79 145  Neck protection aramid, aluminium  R 79 146  Neck protection aramid, short  R 79 146  Neck protection aramid, Dutch version, three-layer  R 79 147  R 79 148  Neck protection aramid, Dutch version, three-layer  R 79 147  R 79 148  R 79 149  R 79 103  R 79 013  R 79 013  R 79 013  R 79 013  R 79 129  R 79 226  R 79 129  R 79 129  R 79 129  R 79 493  Com plug protection for HPS* 7000  R 80 042  R 80 042  R 80 042  Helmet lamp Dräger PX 1 LED  R 62 350  R 62 350  R 79 463  HPS* 7000 facial protection PESU, AS (anti-scratch coated), clear
Accessories / Spare parts  Neck protection aramid, aluminium short  Neck protection aramid, aluminium  R 79 145  R 79 145  Neck protection aramid, aluminium  R 79 145  Neck protection aramid, aluminium  R 79 146  Neck protection aramid, short  R 79 146  Neck protection aramid, Dutch version, three-layer  R 79 147  R 79 148  Neck protection aramid, Dutch version, three-layer  R 79 147  R 79 148  R 79 149  R 79 103  R 79 013  R 79 013  R 79 013  R 79 013  R 79 129  R 79 226  R 79 129  R 79 129  R 79 129  R 79 493  Com plug protection for HPS* 7000  R 80 042  R 80 042  R 80 042  Helmet lamp Dräger PX 1 LED  R 62 350  R 62 350  R 79 463  HPS* 7000 facial protection PESU, AS (anti-scratch coated), clear
Neck protection aramid, aluminium short  Neck protection aramid, aluminium  R 79 145  R 79 146  R 79 146  R 79 146  R 79 146  R 79 147  R 79 148  To attach the integrated LED helmet lamp, order separately: kit front plate for HPS® 7000 helmet lamp  Lamp holder HPS® 7000 (for helmet lamps Dräger PX 1)  Lamp holder for Adaro helmet lamp  Com plug protection for HPS® 7000  R 80 042  R 80 042  Helmet lamp Dräger PX 1 LED  R 62 350  R 79 260  R 79 463  HPS® 7000 facial protection PESU, AS (anti-scratch coated), clear
Neck protection aramid, aluminium short  Neck protection aramid, aluminium  R 79 145  R 79 146  R 79 146  R 79 146  R 79 146  R 79 147  R 79 148  R 79 147  R 79 148  R 79 149  R 79 149  R 79 129  R 79 129
Neck protection aramid, aluminium  Neck protection aramid, aluminium XXL  R 79 480  R 79 146  R 79 146  R 79 146  R 79 146  R 79 147  R 79 148  R 79 146  R 79 146  R 79 147  R 79 148  R 79 149  R 79 149  R 79 149  R 79 129  R 79 129  R 79 129  R 79 129  R 79 493  R 80 042  R 87 9 239  R 79 463  R 79 463  R 79 260  R 79 464  Clear
Neck protection aramid, aluminium XXL  Neck protection aramid, short  R 79 146  R 79 146  R 79 146  R 79 147  R 79 148  R 79 146  R 79 146  R 79 147  R 79 147  R 79 147  R 79 147  R 79 148  R 79 146  R 79 146  R 79 147  R 79 147  R 79 147  R 79 147  R 79 148  R 79 148  R 79 148  R 79 149  R 79 129  R 79 226  R 79 226  R 79 226  R 79 129  R 79 129  R 79 129  R 79 493  R 79 493  R 79 493  R 79 493  R 80 042  R 879 239  R 79 463  R 79 260  R 79 464  Clear
Neck protection aramid, short  Neck protection aramid, Dutch version, three-layer  R 79 147  R 79 148  R 79 148  R 79 149  R 79 013  R 79 013  R 79 226  R 79 226  Front plate for HPS® 7000 helmet lamp  Lamp holder HPS® 7000 (for helmet lamps Dräger PX 1)  R 79 129  R 79 129  R 79 493  R 79 493  R 79 493  Com plug protection for HPS® 7000  R 80 042  R 80 042  R 80 042  Helmet lamp Dräger PX 1 LED  R 62 350  R 62 350  HPS® 7000 facial protection PESU, clear  R 79 239  R 79 463  HPS® 7000 facial protection PESU, AS (anti-scratch coated), clear
Neck protection aramid, Dutch version, three-layer  R 79 147  R 79 148  R 79 103  R 79 103  R 79 226  R 79 226  R 79 226  R 79 129  R 79 129  R 79 129  R 79 129  R 79 493  R 80 042  R 87 9 239  R 79 463  R 79 463  R 79 260  R 79 464  clear
HPS® 7000 helmet lamp LED, integrated R 79 013 R 79 013  To attach the integrated LED helmet lamp, order separately: kit front plate for HPS® 7000 helmet lamp  Lamp holder HPS® 7000 (for helmet lamps Dräger PX 1) R 79 129 R 79 129  Lamp holder for Adaro helmet lamp R 79 493 R 79 493  Com plug protection for HPS® 7000 R 80 042 R 80 042  Helmet lamp Dräger PX 1 LED R 62 350 R 62 350  HPS® 7000 facial protection PESU, clear R 79 239 R 79 463  HPS® 7000 facial protection PESU, AS (anti-scratch coated), clear
To attach the integrated LED helmet lamp, order separately: kit front plate for HPS® 7000 helmet lamp  Lamp holder HPS® 7000 (for helmet lamps Dräger PX 1)  Lamp holder for Adaro helmet lamp  R 79 129  R 79 129  R 79 129  R 79 493  R 79 493  Com plug protection for HPS® 7000  R 80 042  R 80 042  Helmet lamp Dräger PX 1 LED  R 62 350  R 79 239  R 79 463  HPS® 7000 facial protection PESU, AS (anti-scratch coated), clear
Front plate for HPS® 7000 helmet lamp  Lamp holder HPS® 7000 (for helmet lamps Dräger PX 1)  R 79 129  R 79 129  R 79 493  R 79 493  Com plug protection for HPS® 7000  R 80 042  Helmet lamp Dräger PX 1 LED  R 62 350  R 80 042  HPS® 7000 facial protection PESU, clear  R 79 239  R 79 463  R 79 464  clear
Lamp holder HPS* 7000 (for helmet lamps Dräger PX 1)  R 79 129  R 79 129  R 79 493  R 79 493  R 79 493  R 80 042  R 80 042  R 80 042  Helmet lamp Dräger PX 1 LED  R 62 350  R 62 350  R 79 463  HPS* 7000 facial protection PESU, AS (anti-scratch coated), clear
Lamp holder for Adaro helmet lamp  R 79 493 R 79 493 Com plug protection for HPS® 7000 R 80 042 R 80 042 Helmet lamp Dräger PX 1 LED R 62 350 R 62 350 HPS® 7000 facial protection PESU, clear R 79 239 R 79 463 HPS® 7000 facial protection PESU, AS (anti-scratch coated), clear
Com plug protection for HPS* 7000 R 80 042 R 80 042 Helmet lamp Dräger PX 1 LED R 62 350 R 62 350 HPS* 7000 facial protection PESU, clear R 79 239 R 79 463 HPS* 7000 facial protection PESU, AS (anti-scratch coated), R 79 260 R 79 464 clear
Helmet lamp Dräger PX 1 LED  R 62 350  R 62 350  R 79 239  R 79 463  HPS* 7000 facial protection PESU, AS (anti-scratch coated), clear
HPS® 7000 facial protection PESU, clear R 79 239 R 79 463 HPS® 7000 facial protection PESU, AS (anti-scratch coated), clear R 79 260 R 79 464
HPS® 7000 facial protection PESU, AS (anti-scratch coated), clear R 79 260 R 79 464
clear
HPS® 7000 facial protection PESU, gold R 79 262 R 79 465
HPS® 7000 facial protection PESU, AF (anti-fog)  R 79 324  R 79 339
HPS® 7000 eye protection PESU, clear R 79 231 R 79 460
HPS® 7000 eye protection PESU, AS (anti-scratch coated), clear R 79 267 R 79 461
HPS® 7000 eye protection PC, tinted R 79 270 R 79 333
Reflective stripes 3-parts, rear silver R 79 284 R 79 466
red R 79 141 R 79 467
yellow R 79 142 R 79 468
blue R 79 143 R 79 469
orange R 79 169 R 79 470
Reflective stripes 2-parts, rear silver 37 00 631 37 00 632
red R 80 092 R 80 096
yellow R 80 094 R 80 098
blue R 80 093 R 80 097
orange R 80 095 R 80 099
Reflective stripes "wing", lateral red R 80 063 R 80 063
gold R 80 064 R 80 064
silver R 80 065 R 80 065
black R 80 066 R 80 066
Reflective stripes "2 arcs", front         red         37 00 582         37 00 582
gold 37 00 583 37 00 583
silver 37 00 584 37 00 584
black 37 00 585 37 00 585
Reflective stripes, service grade R 79 006 R 79 006
HPS® 7000 customised marking R 80 089 R 80 089
HPS® 7000 head pad for size 50/51 R 79 277
Helmet carrying bag for transport and storage, large R 58 555 R 58 555

# Ordering Information

Helmet carrying bag for transport and storage, small	R 68 555	R 68 555
HPS® 7000 helmet pouch	R 79 282	R 79 282
HPS® 7000 Helmet protection cover (for training purpose)	R 79 279	R 79 279
Washing bag	65 700 03	65 700 03
RFID tag	33 626 17	33 626 17
Barcode label outer edge 30 x 13 mm	AG 02395	AG 02395
Barcode label outer edge 22 x 8 mm	AG 02551	AG 02551

Notes

# 90 41 753 | 19.03-13 | HQ | PP | Subject to modifications | © 2019 Drägerwerk AG & Co. KGaA

Not all products, features, or services are for sale in all countries.

Mentioned Trademarks are only registered in certain countries and not necessarily in the country

in which this material is released. Go to www.draeger.com/trademarks to find the current status.

#### CORPORATE HEADQUARTERS

Drägerwerk AG & Co. KGaA Moislinger Allee 53–55 23558 Lübeck, Germany www.draeger.com

#### **REGION DACH**

Dräger Safety AG & Co. KGaA Revalstraße 1 23560 Lübeck, Germany Tel +49 451 882 0 Fax +49 451 882 2080 info@draeger.com

#### REGION EUROPE

Dräger Safety AG & Co. KGaA Revalstraße 1 23560 Lübeck, Germany Tel +49 451 882 0 Fax +49 451 882 2080 info@draeger.com

#### REGION MIDDLE EAST, AFRICA

Dräger Safety AG & Co. KGaA Branch Office P.O. Box 505108 Dubai, United Arab Emirates Tel +971 4 4294 600 Fax +971 4 4294 699 contactuae@draeger.com

#### REGION ASIA PACIFIC

Draeger Singapore Pte. Ltd. 25 International Business Park #04-20/21 German Centre Singapore 609916 Tel +65 6308 9400 Fax +65 6308 9401 asia.pacific@draeger.com

# REGION CENTRAL AND SOUTH AMERICA

Dräger Panama S. de R.L. 59 East Street, Nuevo Paitilla House 30, San Francisco Town Panama City, Panama Tel +507 377 9100 Fax +507 377 9130 servicioalcliente@draeger.com

Locate your Regional Sales Representative at: www.draeger.com/contact

