

# Dräger PARAT<sup>®</sup> 3200 **Filtering Escape Device**

The Dräger PARAT<sup>®</sup> 3200 is a mouth piece / nose-clip escape device equipped with a multi-gas ABEK15 filter. Packed in a robust and ergonomic case the unit is compact and easy to carry. Approved to the only recognized standard for filtering industrial escape devices (DIN 58647-7) – it provides users a minimum of 15 minutes escape time.



### Robust housing

- Suitable for daily use in rough work environments

# **Benefits**

# Proven protection against a variety of harmful gases

The multi-gas ABEK15 filter provides reliable protection against a wide range of toxic industrial gases.

# Mouth piece with nose clip

The mouth piece with nose clip is easy and safe to don, even for bearded wearers. It provides very low leakage values. The small and compact size makes it easy to carry.

# Robust and ergonomic packaging

The ergonomic design with traction grip areas on the housing allows for easy and safe handling. It is easy to attach the device during daily work using the belt clip. The robust case provides stability and protection even under extreme working conditions.

# **Transparent cover**

The cover is transparent and offers a clear view of the device. Service intervals are easy to keep track of as the expiration date is printed on the filter and can be easily read.

# Protection for at least 15 minutes

The Dräger PARAT 3200 protects the user from a wide range of toxic industrial gases for at least 15 minutes. It is approved in accordance with DIN 58647-7.

# Low cost of ownership

The device has a 12 year total service lifetime provided that the filter is replaced every 4 years, ensuring minimal operational costs.

# **Related Products**



# Dräger PARAT<sup>®</sup> 3100

The Dräger PARAT<sup>®</sup> 3100 is a half mask escape device equipped with a multi-gas ABEK15 filter. Packed in a robust and ergonomic case the unit is compact and easy to carry. Approved to the only recognized standard for filtering industrial escape devices (DIN 58647-7) – it provides users a minimum of 15 minutes escape time.

# **Technical Data**

Filter performance	ABEK15 gas filter for protection against organic and anorganic gases and vapours, approved in accordance to DIN 58647 part 7 at least 15 minutes		
Duration of use			
Shelf life	4 years maintenance free, filter exchange every 4 years, total shelf life 12 years		
Weight	Dräger PARAT <sup>®</sup> 3100	approx. 360 g	
	Dräger PARAT <sup>®</sup> 3200	approx. 330 g	
Dimensions (L x W x H)	Dräger PARAT <sup>®</sup> 3100	170 x 110 x 90 mm	
	Dräger PARAT <sup>®</sup> 3200	170 x 110 x 60 mm	
Approval	approved in accordance to DIN 58647 part 7 (CE mark 0158)		

# Filter capacity according to DIN 58647-7\*

Туре	Test gas	Concentration in	Breakthrough in	Minimum breakthrough
		ppm	ppm	time in min
A	Cyclohexane (C <sub>6</sub> H <sub>12</sub> )	2,500	10	15
В	Chlorine (Cl <sub>2</sub> )	2,500	0.5	15
В	Hydrogen sulphide (H <sub>2</sub> S)	2,500	10	15
В	Hydrogen cyanide (HCN)	2,500	10	15
E	Sulphur dioxide (SO <sub>2</sub> )	2,500	5.0	15
К	Ammonia (NH <sub>3</sub> )	2,500	25	15
В	Hydrogen sulphide (H <sub>2</sub> S)	10,000**	20	5

\* Test conditions: 30 L/min, 70% relative humidity, 20°C.

\*\* To determine the breakthrough capacity of the gas filter it is additionally tested with 10,000 ppm hydrogen sulphide.

# Ordering Information

Dräger PARAT <sup>®</sup> 3100	R 57 981
Half mask with ABEK15 filter	
Dräger PARAT <sup>®</sup> 3200	R 57 982
Mouthbit with noseclip with ABEK15 filter	
Accessories for training units	
PARAT <sup>®</sup> 3100, Housing Cover, blue (training device component)	R 56 353
PARAT <sup>®</sup> 3200, Housing Cover, blue (training device component)	R 56 354
Replacement filters and parts	
ABEK15 Replacement Filter (5 pieces)	R 57 983
PARAT <sup>®</sup> 3000 Security Tag (50 pieces)	R 56 355
PARAT <sup>®</sup> 3000 TPE Sealing Strap	R 56 319
PARAT <sup>®</sup> 3000 Carrying Belt	R 28 175

Notes

Notes

# 91 00 581 | 16.02-1 | Communications & Sales Marketing | PP | LE | Chlorine-free – environmentally compatible | Subject to modifications | @ 2016 Drägerverk AG & Co. KGaA

### CORPORATE HEADQUARTERS

Drägerwerk AG & Co. KGaA Moislinger Allee 53–55 23558 Lübeck, Germany www.draeger.com

### REGION DACH

Dräger Safety AG & Co. KGaA Revalstraße 1 23560 Lübeck, Germany Tel +49 451 882 0 Fax +49 451 882 2080 info@draeger.com

# REGION EUROPE

Dräger Safety AG & Co. KGaA Revalstraße 1 23560 Lübeck, Germany Tel +49 451 882 0 Fax +49 451 882 2080 info@draeger.com

# REGION MIDDLE EAST, AFRICA

Dräger Safety AG & Co. KGaA Branch Office P.O. Box 505108 Dubai, United Arab Emirates Tel +971 4 4294 600 Fax +971 4 4294 699 contactuae@draeger.com

# REGION ASIA PACIFIC

Draeger Safety Asia Pte Ltd 25 International Business Park #04-20/21 German Centre Singapore 609916 Tel +65 6308 9400 Fax +65 6308 9401 asia.pacific@draeger.com

# REGION CENTRAL

AND SOUTH AMERICA Dräger Panama S. de R.L. Complejo Business Park, V tower, 10th floor Panama City Tel +507 377 9100 Fax +507 377 9130 contactcsa@draeger.com

Locate your Regional Sales Representative at: www.draeger.com/contact

