

Dräger PAS[®] ASV Airline Equipment

The Dräger Automatic Switch over Valve (PAS[®] ASV) enables the user to connect compressed air breathing apparatus to an external air supply, such as a factory ring main, and be safe in the knowledge that if the external supply were to fail, there would be a safe and uninterrupted transition to the wearer's back-up air supply.



Dräger. Technology for Life®

Benefits

Warning device

A warning device warns that the wearer is now breathing from cylinder compressed air.

Low profile and light

Due to its compact design the PAS ASV can be used easily in confined spaces.

Uninterrupted airsupply

If the external air supply fails, then the unit will automatically switch to the compressed air breathing apparatus for its supply of air. During the switch over operation the ASV maintains positive pressure within the facemask at all times.

System components



Dräger PAS® Lite

For use in industrial applications where a simple, robust and easy to use breathing apparatus is required, the Dräger PAS[®] Lite Self-Contained Breathing Apparatus (SCBA) combines reliability with comfort and performance.

System components



Dräger PAS® AirPack 1

Designed using leading technology and materials, Dräger's range of heavy-duty airline apparatus is ideal for use where an extended duration of breathing air is called for. Chemical tank cleaning, toxic spillages or certain tasks when working on offshore installations are all made easier and more comfortable when using the Dräger PAS[®] AirPack 1.

Iter Book

Dräger PAS® AirPack 2

Designed using leading technology and materials, Dräger's range of heavy-duty airline apparatus is ideal for use where an extended duration of breathing air is called for. Chemical tank cleaning, toxic spillages or certain tasks when working on offshore installations are all made easier and more comfortable when using the Dräger PAS[®] AirPack 2.



Dräger PAS® Colt

Combining versatility, ease of use and the latest in breathing apparatus design, Dräger's PAS[®] Colt is among the most technologically advanced short duration and emergency escape units available.



3557-2003

Dräger PAS[®] Micro

Combining versatility, ease of use and the latest in breathing apparatus design, Dräger's PAS[®] Micro is among the most technologically advanced short duration and emergency escape units available.

System components



Dräger WorkMaster Industry

Particularly resistant against alkaline solutions and acids. The chemical protection suit WorkMaster Industry provides reliable protection during tank and boiler cleaning, during maintenance and repair work in narrow spaces or refineries, during chemical transports, cleanup operations and many other dangerous types of work.



Dräger ABIL-L

Simple, but effective protection: the compressed airline system ABIL-L offers comfortable respiratory protection during long-term stationary applications.



Dräger ABIL-R

Simple, but effective protection: the compressed airline system ABIL-R offers comfortable respiratory protection during long-term stationary applications.

Technical Data

Weight (g)	350
Dimensions (L x W x H) (mm)	130 x 54 x 32
Supply pressures (bar)	Compressed Air Breathing Apparatus - Nominal 7.5
	External air source 6.0 to 10.0
Switching pressures (bar)	from external source 4.0 to 5.0
	Back to external air source 5.0 to 5.8
Warning device volume (dBA)	90
Operating temperature range (°C)	-30 to +70
Approvals	EN14593 pt1 and EN137**
**for use with Compressed Air Breathing Apparatus	approved to EN137 or EN402

Ordering Information

Dräger PAS ASV

-

Notes

compatible | Subject to modifications | @ 2015 Drägerwerk AG & Co. KGaA utally . nications & Sales Marketing | PP | LE | Printed in Germany | Chlorine-free -90 46 290 | 15-04-3 | Comn

CORPORATE HEADQUARTERS

Drägerwerk AG & Co. KGaA Moislinger Allee 53–55 23558 Lübeck, Germany www.draeger.com

Manufacturer:

Dräger Safety AG & Co. KGaA Revalstraße 1 23560 Lübeck, Germany

REGION EUROPE CENTRAL

AND EUROPE NORTH Dräger Safety AG & Co. KGaA Revalstraße 1 23560 Lübeck, Germany Tel +49 451 882 0 Fax +49 451 882 2080 info@draeger.com

REGION EUROPE SOUTH

Dräger Safety France SAS 25, rue Georges Besse 92182 Antony Cedex Tel +33 1 46 11 56 00 Fax +33 1 40 96 97 20 europe.south@draeger.com

REGION MIDDLE EAST, AFRICA

Dräger Safety AG & Co. KGaA Branch Office P.O. Box 505108 Dubai, United Arab Emirates Tel +971 4 4294 600 Fax +971 4 4294 699 contactuae@draeger.com

REGION ASIA PACIFIC

Draeger Safety Asia Pte Ltd 25 International Business Park #04-20/21 German Centre Singapore 609916 Tel +65 6308 9400 Fax +65 6308 9401 asia.pacific@draeger.com

REGION CENTRAL

AND SOUTH AMERICA Dräger Panama S. de R.L. Complejo Business Park, V tower, 10th floor Panama City Tel +507 377 9100 Fax +507 377 9130 contactcsa@draeger.com

Locate your Regional Sales Representative at: www.draeger.com/contact

