

Dräger X-plore® 6530 Full Face Mask

The full face mask Dräger X-plore® 6530 is the successor to the Panorama Nova® RA masks, meeting the highest demands for quality, reliability and secure fit. The mask body made from EPDM is highly resistant and skin-friendly, offering high wearing comfort.



Benefits

Safe and comfortable fit

A double sealing frame with threefold sealing edges offers safe protection and a secure fit for almost all face shapes. The mask body made from durable EPDM ensures a great level of wearing comfort even during prolonged use.

Large field of vision

The distortion-free lens with 180° wide angle guarantees a large field of vision with excellent periphial vision. You have the choice between a lens made from impact-proof polycarbonate (with either a plastic or stainless steel lens frame) or an extremely scratch-resistant Triplex lens with high chemical resistance (with stainless steel lens frame).

Efficient ventilation system

The efficient ventilation system with separate inner mask ensures a fog-free lens and unobstructed view.

Versatile use

The X-plore 6530 is equipped with an Rd40 connection in accordance with EN 148-1 for use of the Dräger X-plore® Rd40 filter series.

5-point harness

The comfortable 5-point head harness not only ensures that the mask can be donned easily and quickly, but is wide enough to prevent any pressure points on the wearer's head.

Simple servicing and logistics

One universal size simplifies logistics and storage. An inside barcode allows for ease of recording and servicing the mask inventory.

Clear voice communication

An integrated stainless steel voice diaphragm facilitates good communication.

System Components



Dräger X-plore® Rd40 Filters

Whether used in chemical industry or automobile industry, shipbuilding, metal processing industry or by public utility services – for decades Dräger respiratory protection filters have been a synonym for experience and safety worldwide. They clean breathable air from contaminants in a low-cost and effective manner.

Accessories



Wikov V mask box

Instead of a mask bag, the Dräger full face masks can be stored or carried along in the Wikov V mask box.



Lens overlay protectors, self-adhesive

Accessories



Welding protection visor (only for stainless-steel frames)

In combination with a full face mask and corresponding breathing filters, the welding protection visor ensures that you stay safe when welding.



Mask spectacles kit

The full face mask can easily be equipped with a spectacles kit for wearers of glasses.



DAISYquick cleaning cloths

Cleaning cloths to remove dirt easily, without damaging the mask.



Anti-fogging gel "klar-pilot" (50 ml)

This special anti-fog agent (gel) prevents visors and mask spectacles from fogging even in case of extreme temperature differences.

Related Products



Dräger X-plore® 6300

The Dräger X-plore® 6300 is the efficient yet low-cost full face mask intended for price-conscious users not wishing to compromise on comfort or quality. This full face mask is the successor to the Panorama Nova® Standard, a mask which has proven itself over decades of use worldwide – redesigned and improved with fresh colours and an integrated barcode.



Dräger X-plore® 6570

The Dräger X-plore® 6570 is the high comfort full face mask used by professionals in a wide variety of applications. It is the successor to the Panorama Nova® RA masks, a range which has proven itself over decades of use worldwide. Its robust but flexible and skin-friendly mask body made from silicone features high wearing comfort – even when used for long periods of time.

7500 000

Technical Data

Mask body	Highly resistant and hypoallergenic EPDM	
Visor	Choice of impact-resistant polycarbonate or extremely	
	temperature- and chemical-resistant triplex	
Connector	Sturdy plastic with inhalation and exhalation valve, standard thread	
	connection Rd 40x1/7" as per EN 148-1	
Weight	Approx. 550 – 650 g (depending on visor/frame)	
Tested and approved	EN 136 Class 3 (CE mark), NIOSH (PC), AS/NZS	

Ordering Information

Description		Order no.
Dräger X-plore® 6530 EPDM/PC	With PC visor and plastic frame	R 55 795
Dräger X-plore® 6530 EPDM/PC	With PC visor and stainless steel frame	R 51 525
Dräger X-plore® 6530 EPDM/Triplex	With triplex visor and stainless steel frame	R 55 810
Accessories		
Wikov V carrying case		R 51 019
Protex mask bag		R 54 939
Mask spectacles kit		R 51 548
Lens covers (set of 25), self-adhesive		40 55 092
Welding protection visor (only for stainless steel frame)		R 50 270
Anti-fogging gel "klar-pilot" (50 ml)		R 52 560
DAISYquick cleaning cloths (pack of 10)		R 54 134
Welding shield		40 53 437
Adapter for welding shield	for supplementary panels and welding protective filters with a 110 mm x 90 mm	R 57 308
	format	

The compatible Dräger X-plore® Rd40 filter series with standard thread connection as per EN 148-1 includes an extensive range of different particle, gas and combination filters (see separate data sheet Dräger X-plore® Rd40 filters for further details).

Notes

Notes

Not all products, features, or services are for sale in all countries. Mentioned Trademarks are only registered in certain countries and not necessarily in the country in which this material is released. Go to www.draeger.com/trademarks to find the current status.

CORPORATE HEADQUARTERS

Drägerwerk AG & Co. KGaA Moislinger Allee 53–55 23558 Lübeck, Germany www.draeger.com

REGION DACH

Dräger Safety AG & Co. KGaA Revalstraße 1 23560 Lübeck, Germany Tel +49 451 882 0 Fax +49 451 882 2080 info@draeger.com

REGION EUROPE

Dräger Safety AG & Co. KGaA Revalstraße 1 23560 Lübeck, Germany Tel +49 451 882 0 Fax +49 451 882 2080 info@draeger.com

REGION MIDDLE EAST, AFRICA

Dräger Safety AG & Co. KGaA Branch Office P.O. Box 505108 Dubai, United Arab Emirates Tel +971 4 4294 600 Fax +971 4 4294 699 contactuae@draeger.com

REGION ASIA PACIFIC

Draeger Singapore Pte. Ltd. 25 International Business Park #04-20/21 German Centre Singapore 609916 Tel +65 6308 9400 Fax +65 6308 9401 asia.pacific@draeger.com

REGION CENTRAL AND SOUTH AMERICA

Dräger Panama S. de R.L. 59 East Street, Nuevo Paitilla House 30, San Francisco Town Panama City, Panama Tel +507 377 9100 Fax +507 377 9130 servicioalcliente@draeger.com

Locate your Regional Sales Representative at: www.draeger.com/contact

